First Boot

There are two ways to interact with the developer kit:

- 1. With display, keyboard and mouse attached.
- 2. Via connection from another computer **headless mode**.

The display connected mode can be realized by taking the power supply from **micro-USD** port or **DC power supply**. In this case both initial modes (graphic and head-less) are configured with DC power supply.

To enable the power supply through the DC Barrel Power Jack it is necessary to place a jumper on the pins [J48].



Initial Setup with Display Attached

Requirements:

- External monitor
- Keyboard
- Mouse
- DC power supply



Insert the microSD card (*with system image already written to it*) into the slot on the underside of the Jetson Nano module. If you have not yet flashed the microSD you can follow this tutorial **microSD Card Setup**.

Connect the peripherals, mouse, keyboard, monitor and of course the DC power supply.

Press the **Power** button to start the Jetson.

When you boot the first time, the developer kit will take you through some initial setup, including:

- Review and accept NVIDIA Jetson software EULA
- Select system language, keyboard layout, and time zone
- Create username, password, and computer name
- Select APP partition size—it is recommended to use the max size suggested

Initial Setup Headless Mode

To complete setup when no display is attached to the developer kit, you'll need to connect the

developer kit to another computer and then communicate with it via a terminal application (e.g., PuTTY) to handle the USB serial communication on that other computer.

Headless initial configuration requires the developer kit to be powered by a DC power supply with barrel jack connector, since the Micro-USB port is required to access the initial configuration prompts.

Connect your other computer to the developer kit's Micro-USB port.

For Windows users

Right click the Windows Start icon and select "Device Manager."

Apps and Features Mobility Center **Power Options** Event Viewer System Device Manager Network Connections **Disk Management** Computer Management Windows Terminal Windows Terminal (Admin) Task Manager Settings File Explorer Search Run Shut down or sign out Desktop >_

Open the **Ports (COM & LPT)** to find the COM port number for **USB Serial Device** (in this case *COM 3*)



Double click each USB Serial Device entry so you can check its properties. Go to the **Details** tab, in property select **Hardware Ids**. If you see **VID 0955** and **PID 7020**, that USB Serial Device for your Jetson developer kit. Note the COM port name (COM3 in this example) for later use.

Serielles USB-Gerät (COM3) Properties	×
General Port Settings Driver Details Events	
Serielles USB-Gerät (COM3)	
Property	
Hardware Ids 🗸 🗸 🗸	
Value	
USB\VID_0955&PID_7020&REV_0002&MI_02	
USB\VID_0955&PID_7020&MI_02	
OK Cance	sl

Open the COM port on PuTTY

PuTTY is one of the most widely used terminal applications for accessing serial consoles. You can use other terminal applications, but if you don't have any on your Windows PC, you can download PuTTY from here.

Open the PuTTY application. When **Session** is selected in the left **Category** panel, input the COM port name for **Serial line** and **115200** for **Speed**.

Real PuTTY Configuration		?	×
Category: Session Logging Terminal Keyboard	Basic options for your PuTTY se Specify the destination you want to conne Serial line	ession ect to Speed	
Bell Features Features Window Appearance Behaviour Translation Selection	Connection type: Connection type: Raw <u>T</u> elnet Rlogin <u>S</u> SH Load, save or delete a stored session Sav <u>e</u> d Sessions	H O Seri	al
Colours Connection Data Proxy Telnet Rlogin	Default Settings	Load Sa <u>v</u> e Delete	
About <u>H</u> elp	Close window on e <u>x</u> it: Always Never Only on c Open	lean exit <u>C</u> ancel	

Click **Open** to connect to the console.

For Linux users

Locate the tty device Before connecting to your Jetson developer kit for initial setup, check to see what Serial devices are already shown on your Linux computer.

```
$ dmesg | grep --color 'tty'
```

Connect your Linux computer to the developer kit's Micro-USB port and run the same command to find what's newly added.

```
$ dmesg | grep --color 'tty'
...
[xxxxx.xxxxx] cdc_acm 1-5:1.2: ttyACM0: USB ACM device
```

The new serial device is for your Jetson developer kit.

\$ ls -l /dev/ttyACM0
crw-rw---- 1 root dialout 166, 0 Oct 2 02:45 /dev/ttyACM0

Screen command

Install the Screen program on your Linux computer if it is now already available. For example, use this command to install Screen if you are running Ubuntu.

7/14

```
$ sudo apt-get install -y screen
```

Use the device name discovered previously as a command line option for the `screen` command.

```
$ sudo screen /dev/ttyACM0 115200
```

Terminate screen

To terminate your screen session, press C-a + k (Ctrl + a, then k), then press y on confirmation.

Headless First Boot Screenshots

ß	COM3 - PuTTY	_		×
Sys	License For Customer Use of NVIDIA Software License For Customer Use of NVIDIA Software IMPORTANT NOTICE READ CAREFULLY: This License For Customer NVIDIA Software ("LICENSE") is the agreement which governs use software of NVIDIA Corporation and its subsidiaries ("NVIDIA") downloadable herefrom, including computer software and associa printed materials ("SOFTWARE"). By downloading, installing, or or otherwise using the SOFTWARE, you agree to be bound by the bits LICENSE	Use o s of t ated copyin terms	f he g, of	
	this LICENSE. If you do not agree to the terms of this LICENS download the SOFTWARE. RECITALS Use of NVIDIA's products requires three elements: the SOFTWARD	SE, do E, the	not	
	hardware on a graphics controller board, and a personal compu- <0k>	er. T	he	







B COM3 - PuTTY	_		×
System Configuration			
Who are you?			
Select a username for the new account. Your first na choice. The username should start with a lower-case	ame is a reasona letter, which c	ble an	
be followed by any combination of numbers and more 1	lower-case lette	rs.	
Username for your account:			
jetson			
< <mark>0k></mark> <cancel< td=""><td>L></td><td></td><td></td></cancel<>	L>		
Putty	_		×
System Configuration			
Who are you?		_	
A good password will contain a mixture of letter punctuation and should be changed at regular in	rs, numbers and cervals.		
Choose a password for the new user:			

<0k> <cancel></cancel>			



	COM3 - PuTTY	_		\times	
Sys	stem Configuration				
	Network configuration				
	Please enter the hostname for this system.				
	The hostname is a single word that identifies your system to t network. If you don't know what your hostname should be, consu	he 1t you	ır		
	network administrator. If you are setting up your own home net can make something up here.	work,	you		
	Hostname:				
	nano-4GB				
	<ok> <cancel></cancel></ok>				
1	COM3 - PuTTY	_		×	1
				~	
Sys	stem Configuration		_		
Sys	stem Configuration				
Sys	stem Configuration Select Nvpmodel Mode				
Sys	Select Nvpmodel Mode If you are unsure which mode to select, keep the default setti setting can be changed at runtime using the nvpmodel GUI or nv	.ng. Ti pmode:	nis L		
Sy	Select Nvpmodel Mode If you are unsure which mode to select, keep the default setti setting can be changed at runtime using the nvpmodel GUI or nv command line utility. Refer to NVIDIA Jetson Linux Developer G further information.	ng. Ti pmode: Suide :	nis L for		
Sys	Select Nvpmodel Mode If you are unsure which mode to select, keep the default setti setting can be changed at runtime using the nvpmodel GUI or nv command line utility. Refer to NVIDIA Jetson Linux Developer G further information. Select from one of the below nvpmodel modes:	ng. Ti pmode: Suide :	nis L for		
59:	Select Nvpmodel Mode If you are unsure which mode to select, keep the default setti setting can be changed at runtime using the nvpmodel GUI or nv command line utility. Refer to NVIDIA Jetson Linux Developer G further information. Select from one of the below nvpmodel modes: MAXN	ng. Ti pmode: Suide :	nis L for		
59:	Select Nvpmodel Mode If you are unsure which mode to select, keep the default setti setting can be changed at runtime using the nvpmodel GUI or nv command line utility. Refer to NVIDIA Jetson Linux Developer G further information. Select from one of the below nvpmodel modes: MAXN 5W	ng. Ti pmode: Suide :	nis L for		
59:	Select Nvpmodel Mode If you are unsure which mode to select, keep the default setti setting can be changed at runtime using the nvpmodel GUI or nv command line utility. Refer to NVIDIA Jetson Linux Developer G further information. Select from one of the below nvpmodel modes: MAXN 5W <ok></ok>	ng. Ti pmode: Suide :	his L for		
591	Select Nvpmodel Mode If you are unsure which mode to select, keep the default setti setting can be changed at runtime using the nvpmodel GUI or nv command line utility. Refer to NVIDIA Jetson Linux Developer G further information. Select from one of the below nvpmodel modes: MAXN 5W <ok> <cancel></cancel></ok>	ng. Ti pmode: Suide :	his L for		
541	Select Nvpmodel Mode If you are unsure which mode to select, keep the default setti setting can be changed at runtime using the nvpmodel GUI or nv command line utility. Refer to NVIDIA Jetson Linux Developer of further information. Select from one of the below nvpmodel modes: MAXN SW 	ng. Ti rpmode: Suide :	his L for		
541	Select Nvpmodel Mode Select, keep the default setti setting can be changed at runtime using the nvpmodel GUI or nv command line utility. Refer to NVIDIA Jetson Linux Developer G further information. Select from one of the below nvpmodel modes: Select from one of the below nvpmodel modes: SW SW SW	ng. Ti pmode: Suide :	his L for		

```
🗬 COM3 - PuTTY
                                                                             \times
Ubuntu 18.04.5 LTS nano-4GB ttyGS0
nano-4GB login: jetson
Password:
Last login: Wed Jul 21 21:10:08 CEST 2021 on ttyGS0
Welcome to Ubuntu 18.04.5 LTS (GNU/Linux 4.9.253-tegra aarch64)
* Documentation: https://help.ubuntu.com
* Management: https://lanuscape.com/

* Support: https://ubuntu.com/advantage
                   https://landscape.canonical.com
This system has been minimized by removing packages and content that are
not required on a system that users do not log into.
To restore this content, you can run the 'unminimize' command.
35 updates can be applied immediately.
26 of these updates are standard security updates.
To see these additional updates run: apt list --upgradable
To run a command as administrator (user "root"), use "sudo <command>".
See "man sudo root" for details.
jetson@nano-4GB:~$
```

From: https://student-wiki.eolab.de/ - HSRW EOLab Students Wiki

Permanent link: https://student-wiki.eolab.de/doku.php?id=ip:ws2021:lets_plaiy:lab:basic_setup:first_boot



Last update: 2023/01/05 14:38