

# Finding Rzero

The below code is used to get the Rzero value of a particular MQ135 sensor, this is the resistance of the sensor in the presence of clean air.

[Finding\\_Rzero.ino](#)

```
#include "MQ135.h"
const int ANALOGPIN=A0;
MQ135 gasSensor = MQ135(ANALOGPIN);
void setup(){
  Serial.begin(9600);      // sets the serial port to 9600
}
void loop(){
  float rzero = gasSensor.getRZero();
  Serial.println(rzero);
  delay(1000);
}
```

[Back to report](#)

From:

<https://student-wiki.eolab.de/> - HSRW EOLab Students Wiki

Permanent link:

<https://student-wiki.eolab.de/doku.php?id=amc2021:group1:extras:r0:start&rev=1630942728>

Last update: **2023/01/05 14:38**

